



MODEL CCT-B

SUPPLEMENTARY INFORMATION

Location




Installation



Fit spacer between car floor and CCT-B Sensor

Dimensions



Wiring Schematic Diagram

